Practical No:3

Problem statement: Setup a WAN which contains wired as well as wireless LAN by using a packet tracer tool. Demonstrate transfer of a packet from LAN 1 (wired LAN) to LAN2 (Wireless LAN)


Objective:

- 1. Understand how to Create LAN, MAN, WAN
- 2. Understand how to Create wireless LAN using Access Point.

Theory:

Packet Tracer - Configuring Wireless LAN Access

Topology



Addressing Table

Device	Interface	IP Address	Subnet Mask	Default Gateway
	G0/0.10	172.17.10.1	255.255.255.0	N/
				A
R1	G0/0.20	172.17.20.1	255.255.255.0	N/
				A
	G0/0.88	172.17.88.1	255.255.255.0	N/
				A
PC1	NI	172.17.10.21	255.255.255.0	172.17.10.1
	C			
PC2	NI	172.17.20.22	255.255.255.0	172.17.20.1
	C			
PC3	NI	DHCP	DHCP	DHCP Assigned
	C	Assigned	Assigned	
WRS2	NI	172.17.88.25	255.255.255.0	172.17.88.1
	C			

Objectives

Part 1: Configure a

Wireless Router

Part 2: Configure a

Wireless Client Part

3: Verify

Connectivity

Scenario

In this activity, you will configure a Linksys wireless router, allowing for remote access from PCs as well as wireless connectivity with WPA2 security. You will manually configure PC wireless connectivity by entering the Linksys router SSID and password.

Part 1: Configure a Wireless Router

Step 1: Connect the Internet interface of WRS2 to S1.

Connect the WRS2 Internet interface to the S1 F0/7 interface.

Step 2: Configure the Internet connection type.

- a. Click **WRS2** > **GUI** tab.
- b. Set the **Internet Connection type** to **Static IP**.
- c. Configure the IP addressing according to the Addressing Table.

Step 3: Configure the network setup.

- a. Scroll down to **Network Setup**. For the **Router IP** option, set the IP address to **172.17.40.1** and the subnet mask to **255.255.25.0**.
- b. Enable the DHCP server.
- c. Scroll to the bottom of the page and click **Save Settings**.

Step 4: Configure wireless access and security.

- a. At the top of the window, click **Wireless**. Set the **Network Mode** to **Wireless-N Only** and change the SSID to **WRS_LAN**.
- b. Disable **SSID Broadcast** and click **Save Settings**.
- c. Click the **Wireless Security** option.
- d. Change the **Security Mode** from **Disabled** to **WPA2 Personal**.
- e. Configure cisco123 as the passphrase.
- f. Scroll to the bottom of the page and click **Save Settings**.

Part 2: Configure a Wireless Client

Step 1: Configure PC3 for wireless connectivity.

Because SSID broadcast is disabled, you must manually configure **PC3** with the correct SSID and passphrase to establish a connection with the router.

- a. Click PC3 > Desktop > PC Wireless.
- b. Click the **Profiles** tab.
- c. Click New.
- d. Name the new profile Wireless Access.
- e. On the next screen, click **Advanced Setup**. Then manually enter the SSID of **WRS_LAN** on **Wireless Network Name**. Click **Next**.
- f. Choose **Obtain network settings automatically (DHCP)** as the network settings, and then click **Next**.
- g. On Wireless Security, choose WPA2-Personal as the method of encryption and

click Next.

- h. Enter the passphrase cisco123 and click Next.
- i. Click **Save** and then click **Connect to Network**.

Step 2: Verify PC3 wireless connectivity and IP addressing configuration.

The **Signal Strength** and **Link Quality** indicators should show that you have a strong signal. Click **More Information** to see details of the connection including IP addressing information. Close the **PC Wireless** configuration window.

Part 3: Verify Connectivity

All the PCs should have connectivity with one another.

Conclusion: we are understand how to setup wireless LAN

Signature with Date